



Mockup Instructions

For questions or more information please visit SoundGuard.io or contact us at info@soundguard.io or 800-955-3991

1. 1 month prior to mockup, send Mockup Equipment List to painting contractor. Clearly state that this is a minimum 2 day job.
2. 1 month prior to install work with prospective customer, verify that furniture (if needed) will be moved along electrical, telephone, cable receptacle covers and wall hangings ie paintings and mirrors.
3. Verify that vinyl (if needed) will be or has been removed.
4. Verify that a skim coat (if needed) will have been done on the walls.
5. 1 week prior to mockup, ensure that painting contractor is on track with work schedule and equipment.
6. 1 week prior to mockup, communicate with property contact to ensure that timeline still tracks. Make sure both sides have an understanding of acceptable start and stop times for work.
7. File edges off mud mixing paddle, as this will ensure that small pieces of plastic from the sidewalls of the bucket will not be scraped off and sucked into the sprayer.
8. Visit the SoundGuard Youtube channel to watch application views to ensure the correct technique. Contact SoundGuard at info@soundguard.io with any questions
9. 1 day prior to mockup, ensure that furniture is moved away from walls or removed from the room.
10. Get room keys (if needed).
11. 1 day prior to install, ensure that the rooms' HVAC is turned down to the lowest possible temperature and highest possible fan speed.

Day 1 -- 7:30am

12. Plug-in and start dehumidifiers in both rooms. Minimize time in hallways, especially any conversations.
13. Begin masking off with ScotchBlue tape. Use 12" plastic on walls and ceiling. If there is trim, crown molding or baseboards, please tape off adequately.
14. Remove outlet covers and tape over sockets.
15. Install 36" self-adhesive carpet protector out from the wall.
16. Use drop sheets to cover furniture (if needed).

Day 1 -- 10:00am

17. Conduct the sound test (See Sound Test Checklist)

Day 1 -- 10:30am



Mockup Instructions

For questions or more information please visit SoundGuard.io or contact us at info@soundguard.io or 800-955-3991

18. Ensure that all water/mineral spirits are cleared from the sprayer and supply line. This is a critical step in the process. 100% of the water and/or fluids need to be removed from the hose.
19. Mix the product for no less than 3 minutes using the ½ spade handle drill with mud mixer paddle extension

Day 1 -- 11am (1st pass)

20. Apply a horizontal 10-12 wet mil coat on first room wall. Prior to spraying any product, please make sure you visit the SoundGuard Youtube channel to watch application views to ensure the proper technique. Use a 50% overlap.
21. Apply a horizontal 10-12 wet mil coat on second room wall. Use a 50% overlap.

Day 1 -- 12pm (2nd pass)

22. Apply a vertical 10-12 wet mil coat on first room wall. Use a 50% overlap.
23. Apply a vertical 10-12 wet mil coat on second room wall. Use a 50% overlap.

Day 1 -- 1pm (3rd pass)

24. Apply a horizontal 10-12 wet mil coat on first room wall. Use a 50% overlap.
25. Apply a horizontal 10-12 wet mil coat on second room wall. Use a 50% overlap.

Day 1 -- 2pm (4th pass)

26. Apply a vertical 10-12 wet mil coat on first room wall. Use a 50% overlap.
27. Apply a vertical 10-12 wet mil coat on second room wall. Use a 50% overlap.

Day 1 -- 3pm (5th pass)

28. Apply a horizontal 10-12 wet mil coat on first room wall. Use a 50% overlap.
29. Apply a horizontal 10-12 wet mil coat on second room wall. Use a 50% overlap.

Day 1 -- 4pm (6th pass)

30. Apply a vertical 10-12 wet mil coat on first room wall. Use a 50% overlap.
31. Apply a vertical 10-12 wet mil coat on second room wall. Use a 50% overlap.
32. Clean sprayer.
33. Ensure that both fans are still on and that dehumidifier tanks are empty for the overnight curing.



Mockup Instructions

For questions or more information please visit SoundGuard.io or contact us at info@soundguard.io or 800-955-3991

Day 2 -- 8am

34. If there are any noticeable sags or drips, sand out using 120-180 sandpaper.
35. Use quick dry mud to repair any noticeable flaws in the wall.
36. Sand out as needed.

Day 2 -- 9am

37. Using razor blades/box cutters, carefully remove painters tape, masking tape and any plastic used on the walls. Be extremely careful when doing this, as being careless in this step may pull the coating off the walls.
38. Using acoustical caulk, please caulk all seams as needed.

Day 2 -- 11am

39. Apply final/top coats (per customer preferences for color, sheen and brand)

Day 2 -- 2pm

40. Install electrical, internet and cable outlet covers/faceplates after installing the Metacaulk STC cover guards.

Day 2 -- 3pm

41. Perform the "after" sound testing (see Sound Test Checklist).

Day 2 -- 4pm

42. Make sure all equipment and materials are removed from rooms.
43. Make sure all rooms are clean.
44. Upon leaving rooms make sure doors are locked and rooms are secure.