



Installation Instructions

For questions or more information please visit SoundGuard.io or contact us at info@soundguard.io or 800-955-3991

Pre-Installation Checklist

1. Ensure that all equipment on the equipment list is procured and working. File edges off mud mixing paddle, as this will ensure that small pieces of plastic from the sidewalls of the bucket will not be scraped off and sucked into the sprayer.
2. 2-3 days prior to installation, windows should be closed and must remain closed throughout installation process
3. Verify that furniture has been moved out of the rooms
4. Verify that everything has been removed from the walls including pictures, mirrors, etc.
5. Verify that all cable, internet and electric cords have been disconnected
6. Verify that vinyl (if present) has been removed.
7. Verify whether a skim coat on the walls will be needed prior to SoundGuard application
8. Verify timelines and work hours with property.
9. Make sure both sides have an understanding of acceptable start and stop times
10. Visit the SoundGuard Youtube channel to watch application views to ensure the correct technique. Contact SoundGuard at info@soundguard.io with any questions
11. Make sure room keys will be issued upon arrival
12. 1 day prior to install, verify that HVAC in all install rooms has been turned down to the lowest possible temperature and highest possible fan speed.

Day of Installation

13. Upon arrival get dehumidifiers plugged in and running on high
14. Verify that all windows are closed and ensure that they will not be opened during installation.
15. Begin masking off with blue painters tape. Use 12" plastic on walls and ceiling. If there is trim, crown molding or baseboards, please tape off adequately.
16. Remove outlet covers and tape over sockets.
17. Install 36" self-adhesive carpet protector out from the wall.
18. Use drop sheets to cover furniture (if needed).
19. Ensure that all water/mineral spirits are cleared from the sprayer and supply line. This is a critical step in the process. 100% of the water and/or fluids need to be removed from the hose.
20. Mix the product for no less than 3 minutes using the 9+ amp ½ spade handle drill with mud mixer paddle extension



Installation Instructions

For questions or more information please visit SoundGuard.io or contact us at info@soundguard.io or 800-955-3991

Installation = 1st coat

21. Apply horizontal 10-12 wet mil application on wall using 50% overlap
22. Apply vertical 10-12 wet mil application on wall using 50% overlap
23. Turn on fans and face at the wall for increased air flow
24. Do not apply second coat for 2-3 hours or until 1st coat is completely dry to the touch

Installation = 2nd coat

25. Apply horizontal 10-12 wet mil application on wall using 50% overlap
26. Apply vertical 10-12 wet mil application on wall using 50% overlap
27. Turn on fans and face at the wall for increased air flow
28. Do not apply third coat for 2-3 hours or until 2nd coat is completely dry to the touch

Installation = 3rd coat

29. Apply horizontal 10-12 wet mil application on wall using 50% overlap
30. Apply vertical 10-12 wet mil application on wall using 50% overlap
31. Turn on fans and face at the wall for increased air flow
32. Do not apply top coat for 2-3 hours or until 3rd coat is completely dry to the touch

Post-Installation Dry Time

33. Make sure all fans are on
34. Make sure all dehumidifiers are running and tanks are empty

After Fully Dry

35. If there are any noticeable sags or drips, sand out using 120-180 sandpaper
36. Use quick dry mud to repair any noticeable flaws in the wall
37. Sand out as needed

Detailed Finishing

38. Using razor blades/box cutters, carefully remove painters tape, masking tape and any plastic used on the walls. Be extremely careful when doing this, as being careless in this step may pull the coating off the walls
39. Using acoustical caulk, please caulk all seams as needed
40. Apply final/top coats (per customer preferences for color, sheen and brand)
41. Install electrical, internet and cable outlet covers/faceplates after installing the Metacaulk
STC cover guards



Installation Instructions

For questions or more information please visit SoundGuard.io or contact us at info@soundguard.io or 800-955-3991

42. Replace baseboards if needed

Clean Up

43. Make sure all equipment and materials are removed from rooms

44. Make sure all rooms are clean